

Hybrid Inverter

SUN-5K-SG01HP3-EU-AM2

SUN-6K-SG01HP3-EU-AM2

SUN-8K-SG01HP3-EU-AM2

SUN-10K-SG01HP3-EU-AM2


SUN-12K-SG01HP3-EU-AM2

SUN-15K-SG01HP3-EU-AM2

SUN-20K-SG01HP3-EU-AM2

SUN-25K-SG01HP3-EU-AM2

User Manual



Contents

2.1 Product Overview 2.2 Product Size 2.3 Product Features 2.4 Basic System Architecture 2.5 Product handling requirements 3. Installation 3.1 Parts list 3.2 Mounting instructions 3.3 Battery connection 3.4 Grid connection and backup load connection 3.5 PV Connection 3.6 CT Connection 3.6.1 Meter Connection 3.7 Earth Connection 3.9 Wiring System for Inverter 3.10 Wiring diagram 3.11 Typical application diagram of diesel generator 3.12 phase parallel connection diagram 4. OPERATION 4.1 Power ON/OFF 4.2 Operation and Display Panel 5. LCD Display Icons 5.1 Main Screen 5.2 Solar Power Curve 5.3 Curve Page-Solar & Load & Grid 5.4 System Setup Menu 5.5 Basic Setup Menu 5.6 Battery Setup Menu 5.7 System Work Mode Setup Menu 5.9 Generator Port Use Setup Menu 5.9 Generator Port Use Setup Menu 5.10 Advanced Function Setup Menu 5.11 Device Info Setup Menu 6. Mode 7. Limitation of Liability 40-44 8. Datasheet 45-48 9. Appendix I	1. Safety Introductions		
2.2 Product Size 2.3 Product Features 2.4 Basic System Architecture 2.5 Product handling requirements 3. Installation 3.1 Parts list 3.2 Mounting instructions 3.3 Battery connection 3.4 Grid connection and backup load connection 3.5 PV Connection 3.6 CT Connection 3.6.1 Meter Connection 3.7 Earth Connection 3.9 Wiring System for Inverter 3.10 Wiring diagram 3.11 Typical application diagram of diesel generator 3.12 phase parallel connection diagram 4. OPERATION 26 4.1 Power ON/OFF 4.2 Operation and Display Panel 5. LCD Display Icons 5.1 Main Screen 5.2 Solar Power Curve 5.3 Curve Page-Solar & Load & Grid 5.4 System Setup Menu 5.5 Basic Setup Menu 5.6 Battery Setup Menu 5.7 System Work Mode Setup Menu 5.8 Grid Setup Menu 5.9 Generator Port Use Setup Menu 5.10 Advanced Function Setup Menu 5.11 Device Info Setup Menu 6. Mode 7. Limitation of Liability 40-44 8. Datasheet 45-48 9. Appendix I	2. Product instructions		02-05
2.3 Product Features 2.4 Basic System Architecture 2.5 Product handling requirements 3. Installation 3.1 Parts list 3.2 Mounting instructions 3.3 Battery connection 3.4 Grid connection and backup load connection 3.5 PV Connection 3.6 CT Connection 3.6.1 Meter Connection 3.7 Earth Connection 3.9 Wiring System for Inverter 3.10 Wiring diagram 3.11 Typical application diagram of diesel generator 3.12 phase parallel connection diagram 4. OPERATION 4.1 Power ON/OFF 4.2 Operation and Display Panel 5. LCD Display Icons 5.1 Main Screen 5.2 Solar Power Curve 5.3 Curve Page-Solar & Load & Grid 5.4 System Setup Menu 5.5 Basic Setup Menu 5.6 Battery Setup Menu 5.7 System Work Mode Setup Menu 5.8 Grid Setup Menu 5.9 Generator Port Use Setup Menu 5.10 Advanced Function Setup Menu 5.11 Device Info Setup Menu 6. Mode 7. Limitation of Liability 40-44 8. Datasheet 45-48 9. Appendix I	2.1 Product Overview		
2.4 Basic System Architecture 2.5 Product handling requirements 3. Installation	2.2 Product Size		
2.5 Product handling requirements 3. Installation	2.3 Product Features		
3. Installation 05-25 3.1 Parts list 3.2 Mounting instructions 3.3 Battery connection 3.4 Grid connection and backup load connection 3.5 PV Connection 3.6 CT Connection 3.6.1 Meter Connection (mandatory) 3.8 WIFI Connection 3.9 Wiring System for Inverter 3.10 Wiring diagram 3.11 Typical application diagram of diesel generator 3.12 phase parallel connection diagram 4. OPERATION 26 4.1 Power ON/OFF 4.2 Operation and Display Panel 5. LCD Display Icons 27-39 5.1 Main Screen 5.2 Solar Power Curve 5.3 Curve Page-Solar & Load & Grid 5.4 System Setup Menu 5.6 Battery Setup Menu 5.6 Battery Setup Menu 5.7 System Work Mode Setup Menu 5.9 Generator Port Use Setup Menu 5.10 Advanced Function Setup Menu 5.11 Device Info Setup Menu 6. Mode 39-40 7. Limitation of Liability 40-44 8. Datasheet 45-48 9. Appendix I 49-50	2.4 Basic System Architecture		
3.1 Parts list 3.2 Mounting instructions 3.3 Battery connection 3.4 Grid connection and backup load connection 3.5 PV Connection 3.6 CT Connection 3.6 CT Connection 3.7 Earth Connection 3.9 Wiring System for Inverter 3.10 Wiring diagram 3.11 Typical application diagram of diesel generator 3.12 phase parallel connection diagram 4. OPERATION 4.1 Power ON/OFF 4.2 Operation and Display Panel 5. LCD Display Icons 5.1 Main Screen 5.2 Solar Power Curve 5.3 Curve Page-Solar & Load & Grid 5.4 System Setup Menu 5.5 Basic Setup Menu 5.6 Battery Setup Menu 5.7 System Work Mode Setup Menu 5.8 Grid Setup Menu 5.9 Generator Port Use Setup Menu 5.10 Advanced Function Setup Menu 5.11 Device Info Setup Menu 6. Mode 7. Limitation of Liability 8. Datasheet 9. Appendix I	2.5 Product handling requirem	ents	
3.1 Parts list 3.2 Mounting instructions 3.3 Battery connection 3.4 Grid connection and backup load connection 3.5 PV Connection 3.6 CT Connection 3.6.1 Meter Connection 3.7 Earth Connection 3.8 WIFI Connection 3.9 Wiring System for Inverter 3.10 Wiring diagram 3.11 Typical application diagram of diesel generator 3.12 phase parallel connection diagram 4. OPERATION 4.1 Power ON/OFF 4.2 Operation and Display Panel 5. LCD Display Icons 5.1 Main Screen 5.2 Solar Power Curve 5.3 Curve Page-Solar & Load & Grid 5.4 System Setup Menu 5.5 Basic Setup Menu 5.6 Battery Setup Menu 5.7 System Work Mode Setup Menu 5.8 Grid Setup Menu 5.9 Generator Port Use Setup Menu 5.10 Advanced Function Setup Menu 5.11 Device Info Setup Menu 6. Mode 7. Limitation of Liability 8. Datasheet 9. Appendix I	3. Installation		05-25
3.3 Battery connection 3.4 Grid connection and backup load connection 3.5 PV Connection 3.6 CT Connection 3.6.1 Meter Connection 3.7 Earth Connection(mandatory) 3.8 WIFI Connection 3.9 Wiring System for Inverter 3.10 Wiring diagram 3.11 Typical application diagram of diesel generator 3.12 phase parallel connection diagram 4. OPERATION 4.1 Power ON/OFF 4.2 Operation and Display Panel 5. LCD Display Icons 5.1 Main Screen 5.2 Solar Power Curve 5.3 Curve Page-Solar & Load & Grid 5.4 System Setup Menu 5.5 Basic Setup Menu 5.6 Battery Setup Menu 5.7 System Work Mode Setup Menu 5.8 Grid Setup Menu 5.9 Generator Port Use Setup Menu 5.10 Advanced Function Setup Menu 5.11 Device Info Setup Menu 6. Mode 7. Limitation of Liability 40-44 8. Datasheet 45-48 9. Appendix I	3.1 Parts list		05 25
3.3 Battery connection 3.4 Grid connection and backup load connection 3.5 PV Connection 3.6 CT Connection 3.6.1 Meter Connection 3.7 Earth Connection(mandatory) 3.8 WIFI Connection 3.9 Wiring System for Inverter 3.10 Wiring diagram 3.11 Typical application diagram of diesel generator 3.12 phase parallel connection diagram 4. OPERATION 4.1 Power ON/OFF 4.2 Operation and Display Panel 5. LCD Display Icons 5.1 Main Screen 5.2 Solar Power Curve 5.3 Curve Page-Solar & Load & Grid 5.4 System Setup Menu 5.5 Basic Setup Menu 5.6 Battery Setup Menu 5.7 System Work Mode Setup Menu 5.8 Grid Setup Menu 5.9 Generator Port Use Setup Menu 5.10 Advanced Function Setup Menu 5.11 Device Info Setup Menu 6. Mode 7. Limitation of Liability 40-44 8. Datasheet 45-48 9. Appendix I	3.2 Mounting instructions		
3.4 Grid connection and backup load connection 3.5 PV Connection 3.6 CT Connection 3.6.1 Meter Connection 3.7 Earth Connection 3.8 WIFI Connection 3.9 Wiring System for Inverter 3.10 Wiring System for Inverter 3.10 Wiring diagram 3.11 Typical application diagram of diesel generator 3.12 phase parallel connection diagram 4. OPERATION 26 4.1 Power ON/OFF 4.2 Operation and Display Panel 5. LCD Display Icons 5.1 Main Screen 5.2 Solar Power Curve 5.3 Curve Page-Solar & Load & Grid 5.4 System Setup Menu 5.5 Basic Setup Menu 5.6 Battery Setup Menu 5.7 System Work Mode Setup Menu 5.8 Grid Setup Menu 5.9 Generator Port Use Setup Menu 5.10 Advanced Function Setup Menu 5.11 Device Info Setup Menu 6. Mode 7. Limitation of Liability 40-44 8. Datasheet 45-48 9. Appendix I			
3.6 CT Connection 3.6.1 Meter Connection 3.7 Earth Connection(mandatory) 3.8 WIFI Connection 3.9 Wiring System for Inverter 3.10 Wiring diagram 3.11 Typical application diagram of diesel generator 3.12 phase parallel connection diagram 4. OPERATION 4.1 Power ON/OFF 4.2 Operation and Display Panel 5. LCD Display Icons 5.1 Main Screen 5.2 Solar Power Curve 5.3 Curve Page-Solar & Load & Grid 5.4 System Setup Menu 5.5 Basic Setup Menu 5.5 Basic Setup Menu 5.7 System Work Mode Setup Menu 5.8 Grid Setup Menu 5.9 Generator Port Use Setup Menu 5.10 Advanced Function Setup Menu 5.11 Device Info Setup Menu 6. Mode 7. Limitation of Liability 40-44 8. Datasheet 45-48 9. Appendix I	·	ip load connection	
3.6.1 Meter Connection 3.7 Earth Connection(mandatory) 3.8 WIFI Connection 3.9 Wiring System for Inverter 3.10 Wiring diagram 3.11 Typical application diagram of diesel generator 3.12 phase parallel connection diagram 4. OPERATION 26 4.1 Power ON/OFF 4.2 Operation and Display Panel 5. LCD Display Icons 27-39 5.1 Main Screen 5.2 Solar Power Curve 5.3 Curve Page-Solar & Load & Grid 5.4 System Setup Menu 5.5 Basic Setup Menu 5.6 Battery Setup Menu 5.7 System Work Mode Setup Menu 5.8 Grid Setup Menu 5.9 Generator Port Use Setup Menu 5.10 Advanced Function Setup Menu 5.11 Device Info Setup Menu 6. Mode 39-40 7. Limitation of Liability 40-44 8. Datasheet 45-48 9. Appendix I	3.5 PV Connection		
3.7 Earth Connection (mandatory) 3.8 WIFI Connection 3.9 Wiring System for Inverter 3.10 Wiring diagram 3.11 Typical application diagram of diesel generator 3.12 phase parallel connection diagram 4. OPERATION 26 4.1 Power ON/OFF 4.2 Operation and Display Panel 5. LCD Display Icons 5.1 Main Screen 5.2 Solar Power Curve 5.3 Curve Page-Solar & Load & Grid 5.4 System Setup Menu 5.5 Basic Setup Menu 5.6 Battery Setup Menu 5.7 System Work Mode Setup Menu 5.8 Grid Setup Menu 5.9 Generator Port Use Setup Menu 5.10 Advanced Function Setup Menu 5.11 Device Info Setup Menu 6. Mode 7. Limitation of Liability 8. Datasheet 9. Appendix I 49-50	3.6 CT Connection		
3.8 WIFI Connection 3.9 Wiring System for Inverter 3.10 Wiring diagram 3.11 Typical application diagram of diesel generator 3.12 phase parallel connection diagram 4. OPERATION 26 4.1 Power ON/OFF 4.2 Operation and Display Panel 5. LCD Display Icons 5.1 Main Screen 5.2 Solar Power Curve 5.3 Curve Page-Solar & Load & Grid 5.4 System Setup Menu 5.5 Basic Setup Menu 5.6 Battery Setup Menu 5.7 System Work Mode Setup Menu 5.8 Grid Setup Menu 5.9 Generator Port Use Setup Menu 5.10 Advanced Function Setup Menu 5.11 Device Info Setup Menu 6. Mode 7. Limitation of Liability 40-44 8. Datasheet 45-48 9. Appendix I	3.6.1 Meter Connection		
3.9 Wiring System for Inverter 3.10 Wiring diagram 3.11 Typical application diagram of diesel generator 3.12 phase parallel connection diagram 4. OPERATION 26 4.1 Power ON/OFF 4.2 Operation and Display Panel 5. LCD Display Icons 27-39 5.1 Main Screen 5.2 Solar Power Curve 5.3 Curve Page-Solar & Load & Grid 5.4 System Setup Menu 5.5 Basic Setup Menu 5.6 Battery Setup Menu 5.7 System Work Mode Setup Menu 5.8 Grid Setup Menu 5.9 Generator Port Use Setup Menu 5.10 Advanced Function Setup Menu 5.11 Device Info Setup Menu 6. Mode 39-40 7. Limitation of Liability 40-44 8. Datasheet 45-48 9. Appendix I	3.7 Earth Connection(mandate	ory)	
3.10 Wiring diagram 3.11 Typical application diagram of diesel generator 3.12 phase parallel connection diagram 4. OPERATION 26 4.1 Power ON/OFF 4.2 Operation and Display Panel 5. LCD Display Icons 27-39 5.1 Main Screen 5.2 Solar Power Curve 5.3 Curve Page-Solar & Load & Grid 5.4 System Setup Menu 5.5 Basic Setup Menu 5.6 Battery Setup Menu 5.7 System Work Mode Setup Menu 5.8 Grid Setup Menu 5.9 Generator Port Use Setup Menu 5.10 Advanced Function Setup Menu 5.11 Device Info Setup Menu 6. Mode 39-40 7. Limitation of Liability 40-44 8. Datasheet 45-48 9. Appendix I			
3.11 Typical application diagram of diesel generator 3.12 phase parallel connection diagram 4. OPERATION 26 4.1 Power ON/OFF 4.2 Operation and Display Panel 5. LCD Display Icons 27-39 5.1 Main Screen 5.2 Solar Power Curve 5.3 Curve Page-Solar & Load & Grid 5.4 System Setup Menu 5.5 Basic Setup Menu 5.6 Battery Setup Menu 5.7 System Work Mode Setup Menu 5.8 Grid Setup Menu 5.9 Generator Port Use Setup Menu 5.10 Advanced Function Setup Menu 5.11 Device Info Setup Menu 6. Mode 39-40 7. Limitation of Liability 40-44 8. Datasheet 45-48 9. Appendix I 49-50			
3.12 phase parallel connection diagram 4. OPERATION 26 4.1 Power ON/OFF 4.2 Operation and Display Panel 5. LCD Display Icons 27-39 5.1 Main Screen 5.2 Solar Power Curve 5.3 Curve Page-Solar & Load & Grid 5.4 System Setup Menu 5.5 Basic Setup Menu 5.6 Battery Setup Menu 5.7 System Work Mode Setup Menu 5.8 Grid Setup Menu 5.9 Generator Port Use Setup Menu 5.10 Advanced Function Setup Menu 5.11 Device Info Setup Menu 6. Mode 39-40 7. Limitation of Liability 40-44 8. Datasheet 45-48 9. Appendix I		om of diesel generator	
4. OPERATION 26 4.1 Power ON/OFF 4.2 Operation and Display Panel 5. LCD Display Icons 27-39 5.1 Main Screen 5.2 Solar Power Curve 5.3 Curve Page-Solar & Load & Grid 5.4 System Setup Menu 5.5 Basic Setup Menu 5.6 Battery Setup Menu 5.7 System Work Mode Setup Menu 5.8 Grid Setup Menu 5.9 Generator Port Use Setup Menu 5.10 Advanced Function Setup Menu 5.11 Device Info Setup Menu 6. Mode 39-40 7. Limitation of Liability 40-44 8. Datasheet 45-48 9. Appendix I			
4.1 Power ON/OFF 4.2 Operation and Display Panel 5. LCD Display Icons 5.1 Main Screen 5.2 Solar Power Curve 5.3 Curve Page-Solar & Load & Grid 5.4 System Setup Menu 5.5 Basic Setup Menu 5.6 Battery Setup Menu 5.7 System Work Mode Setup Menu 5.8 Grid Setup Menu 5.9 Generator Port Use Setup Menu 5.10 Advanced Function Setup Menu 5.11 Device Info Setup Menu 6. Mode 7. Limitation of Liability 40-44 8. Datasheet 9. Appendix I			26
4.2 Operation and Display Panel 5. LCD Display Icons 27-39 5.1 Main Screen 5.2 Solar Power Curve 5.3 Curve Page-Solar & Load & Grid 5.4 System Setup Menu 5.5 Basic Setup Menu 5.6 Battery Setup Menu 5.7 System Work Mode Setup Menu 5.8 Grid Setup Menu 5.9 Generator Port Use Setup Menu 5.10 Advanced Function Setup Menu 5.11 Device Info Setup Menu 6. Mode 39-40 7. Limitation of Liability 40-44 8. Datasheet 45-48 9. Appendix I			20
5. LCD Display Icons 5.1 Main Screen 5.2 Solar Power Curve 5.3 Curve Page-Solar & Load & Grid 5.4 System Setup Menu 5.5 Basic Setup Menu 5.6 Battery Setup Menu 5.7 System Work Mode Setup Menu 5.8 Grid Setup Menu 5.9 Generator Port Use Setup Menu 5.10 Advanced Function Setup Menu 5.11 Device Info Setup Menu 6. Mode 7. Limitation of Liability 40-44 8. Datasheet 9. Appendix I	•	el	
5.1 Main Screen 5.2 Solar Power Curve 5.3 Curve Page-Solar & Load & Grid 5.4 System Setup Menu 5.5 Basic Setup Menu 5.6 Battery Setup Menu 5.7 System Work Mode Setup Menu 5.8 Grid Setup Menu 5.9 Generator Port Use Setup Menu 5.10 Advanced Function Setup Menu 5.11 Device Info Setup Menu 6. Mode 7. Limitation of Liability 39-40 8. Datasheet 9. Appendix I			27-39
5.2 Solar Power Curve 5.3 Curve Page-Solar & Load & Grid 5.4 System Setup Menu 5.5 Basic Setup Menu 5.6 Battery Setup Menu 5.7 System Work Mode Setup Menu 5.8 Grid Setup Menu 5.9 Generator Port Use Setup Menu 5.10 Advanced Function Setup Menu 5.11 Device Info Setup Menu 6. Mode 7. Limitation of Liability 39-40 8. Datasheet 45-48 9. Appendix I	' '		27 33
5.3 Curve Page-Solar & Load & Grid 5.4 System Setup Menu 5.5 Basic Setup Menu 5.6 Battery Setup Menu 5.7 System Work Mode Setup Menu 5.8 Grid Setup Menu 5.9 Generator Port Use Setup Menu 5.10 Advanced Function Setup Menu 5.11 Device Info Setup Menu 6. Mode 39-40 7. Limitation of Liability 40-44 8. Datasheet 45-48 9. Appendix I			
5.4 System Setup Menu 5.5 Basic Setup Menu 5.6 Battery Setup Menu 5.7 System Work Mode Setup Menu 5.8 Grid Setup Menu 5.9 Generator Port Use Setup Menu 5.10 Advanced Function Setup Menu 5.11 Device Info Setup Menu 6. Mode 39-40 7. Limitation of Liability 40-44 8. Datasheet 45-48 9. Appendix I		k Grid	
5.5 Basic Setup Menu 5.6 Battery Setup Menu 5.7 System Work Mode Setup Menu 5.8 Grid Setup Menu 5.9 Generator Port Use Setup Menu 5.10 Advanced Function Setup Menu 5.11 Device Info Setup Menu 6. Mode 39-40 7. Limitation of Liability 40-44 8. Datasheet 45-48 9. Appendix I 49-50			
5.6 Battery Setup Menu 5.7 System Work Mode Setup Menu 5.8 Grid Setup Menu 5.9 Generator Port Use Setup Menu 5.10 Advanced Function Setup Menu 5.11 Device Info Setup Menu 6. Mode 39-40 7. Limitation of Liability 40-44 8. Datasheet 45-48 9. Appendix I 49-50			
5.7 System Work Mode Setup Menu 5.8 Grid Setup Menu 5.9 Generator Port Use Setup Menu 5.10 Advanced Function Setup Menu 5.11 Device Info Setup Menu 6. Mode 39-40 7. Limitation of Liability 40-44 8. Datasheet 45-48 9. Appendix I 49-50	*		
5.8 Grid Setup Menu 5.9 Generator Port Use Setup Menu 5.10 Advanced Function Setup Menu 5.11 Device Info Setup Menu 6. Mode 39-40 7. Limitation of Liability 40-44 8. Datasheet 45-48 9. Appendix I 49-50		Menu	
5.9 Generator Port Use Setup Menu 5.10 Advanced Function Setup Menu 5.11 Device Info Setup Menu 6. Mode 39-40 7. Limitation of Liability 40-44 8. Datasheet 45-48 9. Appendix I 49-50			
5.10 Advanced Function Setup Menu 5.11 Device Info Setup Menu 6. Mode 39-40 7. Limitation of Liability 40-44 8. Datasheet 45-48 9. Appendix I 49-50	-	Menu	
5.11 Device Info Setup Menu 6. Mode 39-40 7. Limitation of Liability 40-44 8. Datasheet 45-48 9. Appendix I 49-50			
6. Mode 39-40 7. Limitation of Liability 40-44 8. Datasheet 45-48 9. Appendix I 49-50			
8. Datasheet 45-48 9. Appendix I 49-50	6. Mode		39-40
8. Datasheet 45-48 9. Appendix I 49-50	7. Limitation of Liability		40-44
9. Appendix I 49-50			45-48
Transfer to the second			
10. Appendix II	The second		
11. EU Declaration of Conformity 51-52			

About This Manual

The manual mainly describes the product information, guidelines for installation, operation and maintenance. The manual cannot include complete information about the photovoltaic (PV) system.

How to Use This Manual

Read the manual and other related documents before performing any operation on the inverter. Documents must be stored carefully and be available at all times.

Contents may be periodically updated or revised due to product development. The information in this manual is subject to change without notice. The latest manual can be acquired via service@deve.com.cn

1. Safety Introductions

Safety signs



The DC input terminals of the inverter must not be grounded.



Surface high temperature, Please do not touch the inverter case.





The AC and DC circuits must be disconnected separately, and the maintenance personnel must wait for 5 minutes before they are completely



Prohibit disassembling inverter case, there existing shock hazard, which may cause serious injury or death, please ask qualified person to repair.



Please read the instructions carefully before use.

powered off before they can start working.




Do Not put it in the waste bin! Recycle it by licensed professional!

- · This chapter contains important safety and operating instructions. Read and keep this manual for future reference.
- · Before using the inverter, please read the instructions and warning signs of the battery and corresponding sections in the instruction manual.
- · Do not disassemble the inverter. If you need maintenance or repair, take it to a professional service center.
- · Improper reassembly may result in electric shock or fire.
- · To reduce risk of electric shock, disconnect all wires before attempting any maintenance or cleaning. Turning off the unit will not reduce this risk.
- · Caution: Only qualified personnel can install this device with battery.
- Never charge a frozen battery.
- · For optimum operation of this inverter, please follow required specification to select appropriate cable size. It is very important to correctly operate this inverter.
- · Be very cautious when working with metal tools on or around batteries. Dropping a tool may cause a spark or short circuit in batteries or other electrical parts, even cause an explosion.
- · Please strictly follow installation procedure when you want to disconnect AC or DC terminals. Please refer to "Installation" section of this manual for the details.
- Grounding instructions this inverter should be connected to a permanent grounded wiring system. Be sure to comply with local requirements and regulation to install this inverter.
- · Never cause AC output and DC input short circuited. Do not connect to the mains when DC input short circuits.


2. Product Introductions


This is a multifunctional inverter, combining functions of inverter, solar charger and battery charger to offer uninterruptible power support with portable size. Its comprehensive LCD display offers user configurable and easy accessible button operation such as battery charging, AC/solar charging, and acceptable input voltage based on different applications.

2.1 Product Overview



2.2 Product Size





2.3 Product Features

- 230V/400V Three phase Pure sine wave inverter.
- Self-consumption and feed-in to the grid.
- Auto restart while AC is recovering.
- Programmable supply priority for battery or grid.
- Programmable multiple operation modes: On grid, off grid and UPS.
- Configurable battery charging current/voltage based on applications by LCD setting.
- Configurable AC/Solar/Generator Charger priority by LCD setting.
- Compatible with mains voltage or generator power.
- Overload/over temperature/short circuit protection.
- Smart battery charger design for optimized battery performance
- With limit function, prevent excess power overflow to the grid.
- Supporting WIFI monitoring and build-in 2 strings for 1 MPP tracker, 1 string for 1 MPP tracker.
- Smart settable three stages MPPT charging for optimized battery performance.
- Time of use function.
- Smart Load Function.

2.4 Basic System Architecture


The following illustration shows basic application of this inverter.

It also includes following devices to have a complete running system.

- Generator or Utility
- PV modules


Consult with your system integrator for other possible system architectures depending on your requirements.

This inverter can power all kinds of appliances in home or office environment, including motor type appliances such as refrigerator and air conditioner.



2.5 Product handling requirements


Two people stand on both sides of the machine, holding one handles to lift the machine.



3. Installation

3.1 Parts List

Check the equipment before installation. Please make sure nothing is damaged in the package. You should have received the items in the following package:




3.2 Mounting instructions

Installation Precaution

This Hybrid inverter is designed for outdoor use(IP65), Please make sure the installation site meets below conditions:


- · Not in direct sunlight
- \cdot Not in areas where highly flammable materials are stored.
- · Not in potential explosive areas.
- · Not in the cool air directly.
- · Not near the television Antenna or antenna cable.
- · Not higher than altitude of about 2000 meters above sea level.
- · Not in environment of precipitation or humidity(>95%)

Please AVOID direct sunlight, rain exposure, snow laying up during installation and operation. Before connecting all wires, please take off the metal cover by removing screws as shown below:



Considering the following points before selecting where to install:

- \cdot Please select a vertical wall with load-bearing capacity for installation, suitable for installation on concrete or other non-flammable surfaces, installation is shown below.
- · Install this inverter at eye level in order to allow the LCD display to be read at all times.
- · The ambient temperature is recommeded to be between -40~60 $^{\circ}\mathrm{C}$ to ensure optimal operation.
- \cdot Be sure to keep other objects and surfaces as shown in the diagram to guarantee sufficient heat dissipation and have enough space for removing wires.




For proper air circulation to dissipate heat, allow a clearance of approx. 50cm to the side and approx. 50cm above and below the unit. And 100cm to the front.

Mounting the inverter


Remember that this inverter is heavy! Please be careful when lifting out from the package. Choose the recommend drill head(as shown in below pic) to drill 4 holes on the wall, 62-70mm deep.

- 1. Use a proper hammer to fit the expansion bolt into the holes.
- 2. Carry the inverter and holding it, make sure the hanger aim at the expansion bolt, fix the inverter on the wall.
- 3. Fasten the screw head of the expansion bolt to finish the mounting.



3.3 Battery connection

For safe operation and compliance, a separate DC over-current protector or disconnect device is required between the battery and the inverter. In some applications, switching devices may not be required but over-current protectors are still required. Refer to the typical amperage in the table below for the required fuse or circuit breaker size.





Safety Hint:


Please use approved DC cable for battery system.

Model	Cross section (mm²)		
iviouei	Range	Recommended value	
5/6/8/10/12/15/20kW	4-10 (10-6AWG)	6(8AWG)	
25kW	6-16 (10-6AWG)	10(6AWG)	

Chart 3-2

The steps to assemble the DC connectors are listed as follows:


a) Strip off the DC wire about 7mm, disassemble the connector cap nut (see picture 3.3).




b) Crimping metal terminals with crimping pliers as shown in picture 3.4.




c) Insert the contact pin to the top part of the connector and screw up the cap nut to the top part of the connector. (as shown in picture 3.5).





d) Finally insert the DC connector into the positive and negative input of the inverter, shown as picture $3.6\,$






3.3.2 Function port definition








CN1:

CT-R (1,2,7,8): current transformer (CT-R) for "zero export to CT"mode clamps on L1 when in three phase system.

CT-S (3,4,9,10): current transformer (CT-S) for "zero export to CT"mode clamps on L2 when in three phase system.

CT-T (5,6,11,12): current transformer (CT-T) for "zero export to CT"mode clamps on L3 when in three phase system.



Meter: for energy meter communication.

Parallel_1: Parallel communication port 1.

Parallel 2: Parallel communication port 2.

CAN: reserved.

DRM: Logic interface for AS/ NZS 4777.2:2020.

BMS1: BMS port for battery

communication port 1.

BMS2: BMS port for battery

communication port 2.

RS485: RS485 port.


CN2:

G-start (1,2): dry contact signal for startup the diesel generator. When the "GEN signal" is active, the open contact (GS) will switch on (no voltage output).

DRY-1 (3,4): Dry contact output. When the inverter is in off-grid mode and the "signal island mode" is checked, the dry contact will switch on. DRY-2 (5,6): reserved.

RSD+,RSD- (7,8): When battery is connected and the inverter is in "ON" status, it will provide 12Vdc.

SHUT DOWN (9,10,11,12): when the terminal "B" & "B" is short-circuited with additional wire connection, or there's 12Vdc input at the terminal "+ & - ", then the 12Vdc of RSD+ & RSD- will disappear immediately, and the inverter will shutdown immediately.



GS (diesel generator startup signal)

3.4 Grid connection and backup load connection

- · Before connecting to the grid, a separate AC breaker must be installed between the inverter and the grid, and also between the backup load and the inverter. This will ensure the inverter can be securely disconnected during maintenance and fully protected from over current. For the 5/6/8/10/12/15/20/25kW model, the recommended AC breaker for backup load 5/6/8/10kW is 60A, 12/15/20/25kW model, the recommended AC breaker for grid 5/6/8/10kW is 60A, 12/15/20/25kW is 100A.
- · There are three terminal blocks with "Grid" "Load"and "GEN" markings. Please do not misconnect input and output connectors.



All wiring must be performed by a qualified personnel. It is very important for system safety and efficient operation to use appropriate cable for AC input connection. To reduce risk of injury, please use the proper recommended cable as below.

Grid connection and backup load connection (Copper wires) (bypass)

Model	Wire Size	Cable(mm²)	Torque value(max)
5/6/8/10kW	8AWG	6	3.4Nm
12/15/20/25kW	4AWG	16	4.0Nm


Grid connection and backup load connection (Copper wires)

Model	Wire Size	Cable(mm²)	Torque value(max)	
5/6kW	16AWG	1.25	2.8Nm	
8/10/12kW	12AWG	2.5	2.8Nm	
15kW	10AWG	4.0	2.8Nm	
20kW	8AWG	6.0	3.4Nm	
25kW	6AWG	10	3.4Nm	

Chart 3-3 Recommended Size for AC wires

Please follow below steps to implement Grid, load and Gen port connection:

- Before making Grid, load and Gen port connection, be sure to turn off AC breaker or disconnector first.
- 2. Remove insulation sleeve 10mm length, insert the wires according to polarities indicated on the terminal block. Make sure the connection is complete.





Be sure that AC power source is disconnected before attempting to wire it to the unit.

- 3. Then, insert AC output wires according to polarities indicated on the terminal block and tighten terminal. Be sure to connect corresponding N wires and PE wires to related terminals as well.
- 4. Make sure the wires are securely connected.
- 5. Appliances such as air conditioner are required at least 2-3 minutes to restart because it is required to have enough time to balance refrigerant gas inside of circuit. If a power shortage occurs and recovers in short time, it will cause damage to your connected appliances. To prevent this kind of damage, please check manufacturer of air conditioner if it is equipped with time-delay function before installation. Otherwise, this inverter will trigger overload fault and cut off output to protect your appliance but sometimes it still causes internal damage to the air conditioner

3.5 PV Connection

Before connecting to PV modules, please install a separately DC circuit breaker between inverter and PV modules. It is very important for system safety and efficient operation to use appropriate cable for PV module connection.



To avoid any malfunction, do not connect any PV modules with possible leakage current to the inverter. For example, grounded PV modules will cause leakage current to the inverter. When using PV modules, please ensure the PV+ & PV- of solar panel is not connected to the system ground bar.



It is requested to use PV junction box with surge protection. Otherwise, it will cause damage on inverter when lightning occurs on PV modules.

3.5.1 PV Module Selection:

When selecting proper PV modules, please be sure to consider below parameters:

- 1) Open circuit Voltage (Voc) of PV modules can not exceed max. PV array open circuit voltage of inverter.
- 2) Open circuit Voltage (Voc) of PV modules should be higher than min. start voltage.
- 3) The PV modules used to connected to this inverter shall be Class A rating certified according to IEC 61730.

Inverter Model	5kW	6kW	8kW	10kW	12kW	15kW	20kW	25kW
PV Input Voltage					700V (180V-1000V)			
PV Array MPPT Voltage Range	150V-850V							
No. of MPP Trackers	2							
No. of Strings per MPP Tracker		1+	-1		2+	-1	2-	+2

Chart 3-5

3.5.2 PV Module Wire Connection:

- 1. Switch the Grid Supply Main Switch(AC)OFF.
- 2. Switch the DC Isolator OFF.
- 3. Assemble PV input connector to the inverter.



Safety Hint:

When using PV modules, please ensure the PV+ & PV- of solar panel is not connected to the system ground bar.




Safety Hint:

Before connection, please make sure the polarity of PV array matches the "DC+" and "DC-" symbols.



Safety Hint:

Before connecting inverter, please make sure the PV array open circuit voltage is within the 1000V of the inverter.





Safety Hint:


Please use approved DC cable for PV system.

Cable type	Cross section	on (mm²)
cubic type	Range	Recommended value
Industry generic PV cable (model: PV1-F)	2.5-4 (12-10AWG)	4(10AWG)


Chart 3-6

The steps to assemble the DC connectors are listed as follows:


a) Strip off the DC wire about 7mm, disassemble the connector cap nut (see picture 5.3).




b) Crimping metal terminals with crimping pliers as shown in picture 5.4.



c) Insert the contact pin to the top part of the connector and screw up the cap nut to the top part of the connector. (as shown in picture 5.5).



d) Finally insert the DC connector into the positive and negative input of the inverter, shown as picture 5.6






Warning:

Sunlight shines on the panel will generate voltage, high voltage in series may cause danger to life. Therefore, before connecting the DC input line, the solar panel needs to be blocked by the opaque material and the DC switch should be 'OFF', otherwise, the high voltage of the inverter may lead to life-threatening conditions. Please do not switch off DC isolator when the DC current when there is high voltage or current. Technicians need to wait until night to keep safety.




Warning:


Please use its own DC power connector from the inverter accessories. Do not interconnect the connectors of different manufacturers.Max. DC input current should be 20A. if exceeds, it may damage the inverter and it is not covered by Deye warranty.





*Note: when the reading of the load power on the LCD is not correct, please reverse the CT arrow.

3.6.1 Meter Connection











Note:

When the inverter is in the off-grid state, the N line needs to be connected to the earth.




Note:

In final installation, breaker certified according to IEC 60947-1 and IEC 60947-2 shall be installed with the equipment.

3.7 Earth Connection(mandatory)

Ground cable shall be connected to ground plate on grid side this prevents electric shock if the original protective conductor fails.



Earth Connection (Copper wires) (bypass)

Model	Wire Size	Cable(mm ²)	Torque value(max)
5/6/8/10kW	8AWG	6	3.4Nm
12/15/20/25kW	4AWG	16	4.0Nm

Earth Connection (Copper wires)


Model	Wire Size	Cable(mm²)	Torque value(max)
5/6kW	16AWG	1.25	2.8Nm
8/10/12kW	12AWG	2.5	2.8Nm
15kW	10AWG	4.0	2.8Nm
20kW	8AWG	6.0	3.4Nm
25kW	6AWG	10	3.4Nm

The conductor should be made of the same metal as the phase conductors.

3.8 WIFI Connection


For the configuration of Wi-Fi Plug, please refer to illustrations of the Wi-Fi Plug. The Wi-Fi Plug is not a standard configuration, it's optional.






3.10 Wiring diagram

Backup Loads Grid This diagram is an example for an application in which neutral is separated from the PE in the distribution box. For countries such as China, Germany, the Czech Republic, Italy, etc., please follow local wiring reguations! \Box **L**2 F3 ● E-BAR ●●● Distribution box RCD E 2 E Home Loads RCD ● E-BAR Backup ! PE or⊗ Hybrid Inverter Grouding screw hole in the lower right corner BMS --Battery Solar Array




3.11 Typical application diagram of diesel generator



3.12 Three phase parallel connection diagram

Note: For the parallel system, the lead-acid battery is not supported. Please use Deye approved lithium battery.



4. OPERATION

4.1 Power ON/OFF

Once the unit has been properly installed and the batteries are connected well, simply press On/Off button(located on the left side of the case) to turn on the unit. When system without battery connected, but connect with either PV or grid, and ON/OFF button is switched off, LCD will still light up(Display will show OFF), In this condition, when switch on ON/OFF button and select NO battery, system can still working.

4.2 Operation and Display Panel

The operation and display panel, shown in below chart, is on the front panel of the inverter. It includes four indicators, four function keys and a LCD display, indicating the operating status and input/output power information.

LED Indicator		Messages
DC	Green led solid light	PV Connection normal
AC	Green led solid light	Grid Connection normal
Normal	Green led solid light	Inverter operating normal
Alarm	Red led solid light	Malfunction or warning

Chart 4-1 LED indicators


Function Key	Description
Esc	To exit setting mode
Up	To go to previous selection
Down	To go to next selection
Enter	To confirm the selection

Chart 4-2 Function Buttons

5. LCD Display Icons


5.1 Main Screen

The LCD is touchscreen, below screen shows the overall information of the inverter.




- 1.The icon in the center of the home screen indicates that the system is Normal operation. If it turns into "comm./F01~F64", it means the inverter has communication errors or other errors, the error message will display under this icon(F01-F64 errors, detail error info can be viewed in the System Alarms menu).
- 2.At the top of the screen is the time.
- 3.System Setup Icon, Press this set button, you can enter into the system setup screen which including Basic Setup, Battery Setup, Grid Setup, System Work Mode, Generator port use, Advanced function and Li-Batt info.
- 4. The main screen showing the info including Solar, Grid, Load and Battery. Its also displaying the energy flow direction by arrow. When the power is approximate to high level, the color on the panels will changing from green to red so system info showing vividly on the main screen.
- \cdot PV power and Load power always keep positive.
- · Grid power negative means sell to grid, positive means get from grid.
- · Battery power negative means charge, positive means discharge.

5.1.1 LCD operation flow chart




5.2 Solar Power Curve



This is Solar Panel detail page.

- 1 Solar Panel Generation.
- 2 Voltage, Current, Power for each MPPT.
- 3 Daily and total PV production.

Press the "Energy "button will enter into the power curve page.




This is Inverter detail page.

Inverter Generation.

Voltage, Current, Power for each Phase.

AC-T: mean Heat-sink temperature.



This is Load detail page.

- 1 Load Power.
- Voltage, Power for each Phase.
- Oaily and total Load consumption .

When you check "Selling First" or "Zero export to Load" on system work mode page, the information on this page is about backup load which connect on Load port of hybrid inverter.
When you check "Zero export to CT" on system work mode page, the information on this page is including backup load and home load.

backup load and home load.

Press the "Energy" button will enter into the power curve page.



This is Grid detail page.


- 1 Status, Power, Frequency.
- 2 L: Voltage for each Phase
 - CT: Power detected by the external current
 - LD: Power detected using internal sensors on AC grid in/out breaker
- 3 BUY: Energy from Grid to Inverter,
 - SELL: Energy from Inverter to grid.

Press the "Energy" button will enter into the power curve page.




This is Battery detail page.


if you use Lithium Battery, you can enter BMS page.



5.3 Curve Page-Solar & Load & Grid










Solar power curve for daily, monthly, yearly and total can be roughly checked on the LCD, for more accuracy power generation, pls check on the monitoring system. Click the up and down arrow to check power curve of different period.

5.4 System Setup Menu



5.5 Basic Setup Menu



Factory Reset: Reset all parameters of the inverter. Lock out all changes: Enable this menu for setting parameters that require locking and cannot be set up. Before performing a successful factory reset and locking the systems, to keep all changes you need to type in a password to enable the setting.

The password for factory settings is 9999 and for lock out is 7777.



Factory Reset Password: 9999

Lock out all changes Password: 7777

5.6 Battery Setup Menu



Battery capacity: it shows your battery bank size to Deye hybrid inverter.

Use Batt V: Use Battery Voltage for all the settings (V).

Max. A charge/discharge: Max battery charge/discharge current(0-30A for 5/6kW model, 0-37A for 8/10/12/15/20kW model, 0-50A for 25kW model).

For AGM and Flooded, we recommend Ah battery size x 20%= Charge/Discharge amps.

. For Lithium, we recommend Ah battery size x 50% = Charge/Discharge amps.

. For Gel, follow manufacturer's instructions.

No Batt: tick this item if no battery is connected to the system.

Parallel bat1&bat2: if one set of battery was connected Bat 1 and Bat 2 then please enable this function.



This is Grid Charge, you need select.

Start =30%: No use, Just for customization.

A = 37A: It indicates the Current that the Grid charges the Battery.

Grid Charge: It indicates that the grid charges

the battery.

Grid Signal: Disable.

This is Battery Setup page.



Start =30%: Percent SOC below 30% system will AutoStart a connected generator to charge the battery bank.


A = **20A**: Charge rate of 20A from the attached generator in Amps.

Gen Charge: uses the gen input of the system to charge battery bank from an attached generator.


Gen Signal: Normally open relay that closes when the Gen Start signal state is active.

Gen Max Run Time: It indicates the longest time Generator can run in one day, when time is up, the Generator will be turned off. 24H means that it does not shut down all the time.


Gen Down Time: It indicates the delay time of the Generator to shut down after it has reached the running time.



This page tells the PV and diesel generator power the load and battery.



This page tells generator output voltage, frequency, power. And, how much energy is used from generator.



Lithium Mode: This is BMS protocol.Please reference the document(Approved Battery).

Shutdown 10%: It indicates the inverter will shutdown if the SOC below this value.

Low Batt 20%: It indicates the inverter will alarm if the SOC below this value.

Restart 40%: Battery SOC at 40% AC output will resume.

Recommended battery settings

Battery Type	Absorption Stage	Float Stage	Torque value (every 30 days 3hr)
Lithium	Follow its BMS voltage parameters		eters

5.7 System Work Mode Setup Menu




Work Mode

Selling First: This Mode allows hybrid inverter to sell back any excess power produced by the solar panels to the grid. If time of use is active, the battery energy also can be sold into grid.


The PV energy will be used to power the load and charge the battery and then excess energy will flow to grid. Power source priority for the load is as follows:

- 1. Solar Panels.
- 2. Grid.
- 3. Batteries (until programable % discharge is reached).

Zero Export To Load: Hybrid inverter will only provide power to the backup load connected. The hybrid inverter will neither provide power to the home load nor sell power to grid. The built-in CT will detect power flowing back to the grid and will reduce the power of the inverter only to supply the local load and charge the battery.



Zero Export To CT: Hybrid inverter will not only provide power to the backup load connected but also give power to the home load connected. If PV power and battery power is insufficient, it will take grid energy as supplement. The hybrid inverter will not sell power to grid. In this mode, a CT is needed. The installation method of the CT please refer to chapter 3.6 CT Connection. The external CT will detect power flowing back to the grid and will reduce the power of the inverter only to supply the local load, charge battery and home load.



Solar Sell: "Solar sell" is for Zero export to load or Zero export to CT: when this item is active, the surplus energy can be sold back to grid. When it is active, PV Power source priority usage is as follows: load consumption and charge battery and feed into grid.

Max. sell power: Allowed the maximum output power to flow to grid.

Zero-export Power: for zero-export mode, it tells the grid output power. Recommend to set it as 20-100W to ensure the hybrid inverter won't feed power to grid.


Energy Pattern: PV Power source priority.


Batt First: PV power is firstly used to charge the battery and then used to power the load. If PV power is insufficient, grid will make supplement for battery and load simultaneously.

Load First: PV power is firstly used to power the load and then used to charge the battery. If PV power is insufficient, Grid will provide power to load.

Max Solar Power: allowed the maximum DC input power.

Grid Peak-shaving: when it is active, grid output power will be limited within the set value. If the load power exceeds the allowed value, it will take PV energy and battery as supplement. If still can't meet the load requirement, grid power will increase to meet the load needs.





Time of use: it is used to program when to use grid or generator to charge the battery, and when to discharge the battery to power the load. Only tick "Time Of Use" then the follow items (Grid, charge, time, power etc.) will take effect.

Note: when in selling first mode and click time of use, the battery power can be sold into grid.

Gen charge: utilize diesel generator to charge the battery in a time period.

Time: real time, range of 01:00-24:00.

Note: when the grid is present, only the "time of use" is ticked, then the battery will discharge. Otherwise, the battery won't discharge even the battery SOC is full. But in the off-grid mode (when grid is not available, inverter will work in the off-grid mode automatically), the battery will discharge without selecting the "Time Of Use".

Power: Max. discharge power of battery allowed. **Batt(V or SOC %):** battery SOC % or voltage at when the action is to happen.

For example

During 00:00-05:00,

if battery SOC is lower than 80%, it will use grid to charge the battery until battery SOC reaches 80%.

During 05:00-08:00,

if battery SOC is higher than 40%, hybrid inverter will discharge the battery until the SOC reaches 40%. At the same time, if battery SOC is lower than 40%, then grid will charge the battery SOC to 40%. During 08:00-10:00,

if battery SOC is higher than 40%, hybrid inverter will discharge the battery until the SOC reaches 40%.

During 10:00-15:00,


when battery SOC is higher than 80%, hybrid inverter will discharge the battery until the SOC reaches 80%.

During 15:00-18:00,

when battery SOC is higher than 40%, hybrid inverter will discharge the battery until the SOC reaches 40%.

During 18:00-00:00,


when battery SOC is higher than 35%, hybrid inverter will discharge the battery until the SOC reaches 35%.



It allows users to choose which day to execute the setting of "Time of Use".

For example, the inverter will execute the time of use page on Mon/Tue/Wed/Thu/Fri/Sat only.

5.8 Grid Setup Menu




Grid Mode:

General Standard、UL1741 & IEEE1547、CPUC RULE21、SRD-UL-1741、CEI 0_21_Internal、ENS0549_CZ-PPDS(>16A)、Australia_A、Australia_B、Australia_C、AS4777_NewZealand、VDE4105、OVE-Directive R25、EN50549_CZ_PPDS_L16A、NRS097、G98、G99、EN50549_1_Norway_133V、EN50549_1_Norway_230V、Japan_200VAC_3P3W、CEI_0_21_External、CEI_0_21_Areti、Japan_400VAC_3P3W、Japan_415VAC_3P4W、EN50549_1_Switzerland. Please follow the local grid code and then choose the corresponding grid standard.


Grid level: there're several voltage levels for the inverter output voltage when it is in off-grid mode. LN:220V/LL:380V(AC), LN:230V/LL:400V(AC).

IT system: If the grid system is IT system, then please enable this option. For example, the IT grid system voltage is 230Vac (the Line voltage between any two live lines in a three-phase circuit is 230Vac, and the diagram is as follow) then please enable "IT system" and tick the "Grid level" as LN:230V/LL:400V(AC) as below picture shows.



Rz: Large resistance ground resistor. Or the system doesn't have Neutral line






Normal connect: The allowed grid voltage/frequency range when the inverter first time connect to the grid. **Normal Ramp rate**: It is the startup power ramp.

Reconnect after trip: The allowed grid voltage /frequency range for the inverter connects the grid after the inverter trip from the grid.

Reconnect Ramp rate: It is the reconnection power ramp.

Reconnection time: The waiting time period for the inverter connects the grid again.

PF: Power factor which is used to adjust inverter reactive power.



HV1: Level 1 overvoltage protection point;

1 HV2: Level 2 overvoltage protection point;

1 LV1: Level 3 overvoltage protection point.

1 LV1: Level 1 undervoltage protection point;

1 LV2: Level 2 undervoltage protection point;

1 LV3: Level 3 undervoltage protection point;

1 LV4: Level 3 undervoltage protection point;

1 LV5: Level 1 over frequency protection point;

1 Level 1 over frequency protection point;


1 Level 2 over frequency protection point.

1 Level 3 under frequency protection point;

1 LF2: Level 2 under frequency protection point;

1 LF3: Level 3 under frequency protection point;


1 LF3: Level 3 under frequency protection point.



FW: this series inverter is able to adjust inverter output power according to grid frequency.

Droop F: percentage of nominal power per Hz For example, "Start freq F>50.2Hz, Stop freq F<51.5, Droop F=40%PE/Hz" when the grid frequency reaches 50.2Hz, the inverter will decrease its active power at Droop F of 40%. And then when grid system frequency is less than 50.1Hz, the inverter will stop decreasing output power.

For the detailed setup values, please follow the local grid code.




V(W): It is used to adjust the inverter active power according to the set grid voltage.

V(Q): It is used to adjust the inverter reactive power according to the set grid voltage.

This function is used to adjust inverter output power (active power and reactive power) when grid voltage changes.

Lock-in/Pn 5%: When the inverter active power is less than 5% rated power, the VQ mode will not take effect. Lock-out/Pn 20%: If the inverter active power is increasing from 5% to 20% rated power, the VQ mode will take effect again.

For example: V2=110%, P2=80%. When the grid voltage reaches the 110% times of rated grid voltage, inverter output power will reduce its active output power to 80% rated power. For example: V1=94%, Q1=44%. When the grid voltage reaches the 94% times of rated grid voltage, inverter output power will output 44% reactive output power. For the detailed setup values, please follow the local grid code




P(Q): It is used to adjust the inverter reactive power according to the set active power.
P(PF): It is used to adjust the inverter PF according to the set active power.

For the detailed setup values, please follow the local grid code.

Lock-in/Pn 50%: When the inverter output active power is less then 50% rated power, it won't enter the P(PF)


Lock-out/Pn 50%: When the inverter output active power is higher then 50% rated power, it will enter the P(PF) mode.

Note: only when the grid voltage is equal to or higher than 1.05times of rated grid voltage, then the P(PF) mode will take effect.



Reserved: This function is reserved. It is not recommended.

5.9 Generator Port Use Setup Menu



Generator input rated power: allowed Max. power from diesel generator.

GEN connect to grid input: connect the diesel generator to the grid input port.

Smart Load Output: This mode utilizes the Gen input connection as an output which only receives power when the battery SOC is above a user programmable threshold.

e.g. ON: 100%, OFF: 95%: When the battery bank SOC reaches 100%, Smart Load Port will switch on automatically and power the load connected. When the battery bank SOC < 95% , the Smart Load Port will switch off automatically.

Smart Load OFF Batt

• Battery SOC at which the Smart load will switch off.

Smart Load ON Batt

- Battery SOC at which the Smart load will switch on. simultaneously and then the Smart load will switch on.

 On Grid always on: When click "on Grid always on" the smart load will switch on when the grid is present.


 Micro Inv Input: To use the Generator input port as a micro-inverter on grid inverter input (AC coupled), this feature will also work with "Grid-Tied" inverters.
- * Micro Inv Input OFF: when the battery SOC exceeds setting value, Microinveter or grid-tied inverter will shut down.

 * Micro Inv Input ON: when the battery SOC is lower than setting value, Microinveter or grid-tied inverter will start to work.

AC Couple Frz High: If choosing "Micro Inv input", as the battery SOC reaches gradually setting value (OFF), during the process, the microinverter output power will decrease linear. When the battery SOC equals to the setting value (OFF), the system frequency will become the setting value (AC couple Frz high) and the Microinverter will stop working. MI export to grid cutsoff: Stop exporting power produced by the microinverter to the grid.

* Note: Micro Inv Input OFF and On is valid for some certain FW version only.

5.10 Advanced Function Setup Menu




Solar Arc Fault ON: This is only for US.

System selfcheck: Disable. this is only for factory. Gen Peak-shaving: Enable When the power of the generator exceeds the rated value of it, the inverter will provide the redundant part to ensure that the generator will not overload.

DRM: For AS4777 standard.

Backup Delay: When the grid cuts off, the inverter will give output power after the setting time. For example, backup delay: 3ms. the inverter will give output power after 3ms when the grid cuts off. Note: for some old FW version, the function is not available

Signal island mode: If "Signal island mode" is checked and When inverter is in off-grid mode, the relay on the Neutral line (load port N line) will switch ON then the N line (load port N line) will bind to inverter ground.



Asymmetric phase feeding: If it was checked, the inverter will take power from the grid balance of on each phase (L1/L2/L3) when needed.



Ex_Meter For CT: when using zero-export to CT mode, the hybrid inverter can select EX_Meter For CT function and use the different meters.e.g.CHNT and Eastron.

5.11 Device Info Setup Menu




This page show Inverter ID, Inverter version and alarm codes

HMI: LCD version


MAIN: Control board FW version

6. Mode


Mode I:Basic




Mode II: With Generator



Mode III: With Smart-Load



Mode IV: AC Couple





The 1st priority power of the system is always the PV power, then 2nd and 3rd priority power will be the battery bank or grid according to the settings. The last power backup will be the Generator if it is available.

7. Limitation of Liability

In addition to the product warranty described alone, the state and local laws and regulations provide financial compensation for the product's power connection (including violation of implied terms and warranties). The company hereby declares that the terms and conditions of the product and the policy can and can only legally exclude all liability within a limited scope.

Error code	Description	Solutions
F01	DC_Inversed_Failure	Check the PV input polarity Seek help from us, if can not go back to normal state.
F07	DC_START_Failure	 The BUS voltage can't be built from PV or battery. Restart the inverter, If the fault still exists, please contact us for help
F13	Working_Mode_change	1. When the grid type and frequency changed it will report F13; 2. When the battery mode was changed to "No battery" mode, it will report F13; 3. For some old FW version, it will report F13 when the system work mode changed; 4, Generally, it will disappear automatically when shows F13; 5. If it remains same, turn on DC and AC switch for one minute, then turn on the DC and AC switch.; 6. Seek help from us, if can not go back to normal state.
F15	AC_OverCurr_SW_Failure	AC side over current fault 1. Please check whether the backup load power and common load power are within the range; 2. Restart and check whether it is normal; 3. Seek help from us, if can not go back to normal state.
F16	GFCI_Failure	Leakage current fault 1, Check the PV side cable ground connection 2, Restart the system 2-3 times 3, if the fault still existing, please contact us for help.
F18	Tz_Ac_OverCurr_Fault	AC side over current fault 1. Please check whether the backup load power and commonload power are within the range; 2. Restart and check whether it is normal; 3. Seek help from us, if cannot go back to normal state.
F20	Tz_Dc_OverCurr_Fault	DC side over current fault 1. Check PV module connection and battery connection; 2. When in the off-grid mode, the inverter startup with big power load, it may report F20. Please reduce the load power connected; 3. If it remains same, turn on DC and AC switch for one minute, then turn on the DC and AC switch.; 4. Seek help from us, if can not go back to normal state.

Error code	Description	Solutions
F21	Tz_HV_Overcurr_fault	BUS over current. 1, Check the PV input current and battery current setting 2. Restart the system 2~3 times. 3. If the fault still exists, please contact us for help.
F22	Tz_EmergStop_Fault	Remotely shutdown 1, it tells the inverter is remotely controlled.
F23	Tz_GFCI_OC_Fault	Leakage current fault 1. Check PV side cable ground connection. 2. Restart the system 2~3 times. 3. If the fault still exists, please contact us for help.
F24	DC_Insulation_Fault	PV isolation resistance is too low 1. Check the connection of PV panels and inverter is firmly and correctly; 2. Check whether the PE cable of inverter is connected to ground; 3. Seek help from us, if can not go back to normal state.
F26	BusUnbalance_Fault	 Please wait for a while and check whether it is normal; When the load power of 3 phases is big different, it will report the F26. When there' s DC leakage current, it will report F26. Restart the system 2~3 times. Seek help from us, if can not go back to normal state.
F29	Parallel_Comm_Fault	When in parallel mode, check the parallel communication cable connection and hybrid inverter communication address setting; During the parallel system startup period, inverters will report F29.But when all inverters are in ON status, it will disappear automatically; If the fault still exists, please contact us for help.
F34	AC_Overload_Fault	Check the backup load connection, make sure it is in allowed power range If the fault still exists, please contact us for help
F41	Parallel_system_Stop	1, Check the hybrid inverter work status. If there's 1pcs hybrid inverter shutdown, all hybrid inverters will report F41 fault. 2, If the fault still exists, please contact us for help
F42	Parallel_Version_Fault	Check whether the inverter version is consistent. Please contact us to upgrade the software version.

Error code	Description	Solutions
F47	AC_OverFreq_Fault	Grid frequency out of range 1. Check the frequency is in the range of specification or not; 2. Check whether AC cables are firmly and correctly connected; 3. Seek help from us, if can not go back to normal state.
F48	AC_UnderFreq_Fault	Grid frequency out of range 1. Check the frequency is in the range of specification or not; 2. Check whether AC cables are firmly and correctly connected; 3. Seek help from us, if can not go back to normal state.
F52	DC_VoltHigh_Fault	BUS voltage is too high 1. Check whether battery voltage is too high; 2. check the PV input voltage, make sure it is within the allowed range; 3. Seek help from us, if can not go back to normal state.
F53	DC_VoltLow_Fault	BUS voltage is too low 1. Check whether battery voltage is too low; 2. If the battery voltage is too low, using PV or grid to charge the battery; 3. Seek help from us, if can not go back to normal state.
F54	BAT2_VoltHigh_Fault	Check the battery 2 terminal voltage is high; Restart the inverter 2 times and restore the factory settings; Seek help from us, if can not go back to normal state.
F55	BAT1_VoltHigh_Fault	Check the battery 1 terminal voltage is high; Restart the inverter 2 times and restore the factory settings; Seek help from us, if can not go back to normal state.
F56	BAT1_VoltLow_Fault	Check the battery 1 terminal voltage is low; Restart the inverter 2 times and restore the factory settings; Seek help from us, if can not go back to normal state.
F57	BAT2_VoltLow_Fault	Check the battery 2 terminal voltage is low; Restart the inverter 2 times and restore the factory settings; Seek help from us, if can not go back to normal state.
F58	Battery_comm_Lose	1, It tells the communication between hybrid inverter and battery BMS disconnected when "BMS_Err-Stop" is active; 2, If don't want to see this happen, you can disable "BMS_Err-Stop" item on the LCD; 3, If the fault still exists, please contact us for help
F62	DRMs0_stop	the DRM function is for Australia market only; Check the DRM function is active or not; Seek help from us, if can not go back to normal state after restart the system.
F63	ARC_Fault	ARC fault detection is only for US market; Check PV module cable connection and clear the fault; Seek help from us, if can not go back to normal state
F64	Heatsink_HighTemp_Fault	Heat sink temperature is too high 1. Check whether the working environment temperature is too high; 2. Turn off the inverter for 10mins and restart; 3. Seek help from us, if can not go back to normal state.

Under the guidance of our company, customers return our products so that our company can provide service of maintenance or replacement of products of the same value. Customers need to pay the necessary freight and other related costs. Any replacement or repair of the product will cover the remaining warranty period of the product. If any part of the product or product is replaced by the company itself during the warranty period, all rights and interests of the replacement product or component belong to the company.

Factory warranty does not include damage due to the following reasons:

- · Damage during transportation of equipment;
- · Damage caused by incorrect installation or commissioning;
- · Damage caused by failure to comply with operation instructions, installation instructions or maintenance instructions;
- · Damage caused by attempts to modify, alter or repair products;
- · Damage caused by incorrect use or operation;
- · Damage caused by insufficient ventilation of equipment;
- · Damage caused by failure to comply with applicable safety standards or regulations;
- · Damage caused by natural disasters or force majeure (e.g. floods, lightning, overvoltage, storms, fires, etc.)

In addition, normal wear or any other failure will not affect the basic operation of the product. Any external scratches, stains or natural mechanical wear does not represent a defect in the product.

8. Datasheet

Model	SUN-5K-SG01HP3- EU-AM2	SUN-6K-SG01HP3- EU-AM2	SUN-8K-SG01HP3- EU-AM2	SUN-10K-SG01HP3- EU-AM2	
Battery Input Data		<u>'</u>			
Battery Type		Lithiu	ım-ion		
Battery Voltage Range(V)		160	-700		
Max. Charging Current(A)		30	37		
Max. Discharging Current(A)		30	3	37	
Charging Strategy for Li-ion Battery		Self-adapti	-		
Number of Battery Input			1		
PV String Input Data					
Max. PV Input Power(W)	6500	7800	10400	13000	
Max. PV Input Voltage (V)		10	00	•	
Start-up Voltage(V)		18	30		
MPPT Voltage Range(V)		150-	-850		
Full Load MPPT Voltage Range(V)	195-850	195-850	260-850	325-850	
Rated PV Input Voltage (V)		60	00		
Max. Operating PV Input Current(A)	20+20	20+20	20+20	20+20	
Max. Input Short-Circuit Current(A)	30+30	30+30	30+30	30+30	
No. of MPP Trackers/No. of Strings per MPP Tracker		2/2	l+1		
Max. Inverter Backfeed Current To the Array		()		
AC Input/Output Data					
Rated AC Input/Output Active Power(W)	5000	6000	8000	10000	
Max. AC Input/Output Apparent Power(VA)	5500	6600	8800	11000	
Peak Power (off-grid)(W)		1.5 time of rat	ed power, 10 S		
Rated AC Input/Output Current(A)	7.6/7.3	9.1/8.7	12.2/11.6	15.2/14.5	
Max. AC Input/Output Current(A)	8.4/8.0	10/9.6	13.4/12.8	16.7/16	
Max. Three-phase Unbalanced Output Current(A)	13	13	18	22	
Max. Continuous AC Passthrough (grid to load)(A)		4	0		
Rated Input/Output Voltage/Range(V)		220/380V, 230/4	00V 0.85Un-1.1U	In	
Grid Connection Form		3L+I	N+PE		
Rated Input/Output Grid Frequency/Range		50Hz/45Hz-55Hz	60Hz/55Hz-65H	lz	
Power Factor Adjustment Range		0.8 leading t	to 0.8 lagging		
Total Current Harmonic Distortion THDi			ninal power)		
DC Injection Current		<0.5	 5% In		
Efficiency					
Max. Efficiency		97.	60%		
Euro Efficiency			00%		
MPPT Efficiency	>99%				
Equipment Protection					
DC Polarity Reverse Connection Protection		Y	es		
AC Output Overcurrent Protection	Yes				
AC Output Overvoltage Protection			es		
AC Output Short Circuit Protection					
Thermal Protection	Yes Yes				
DC Terminal Insulation Impedance Monitoring					
DC Component Monitoring			es es		
Ground Fault Current Monitoring			es		
Ground rault current wonttornig		Y	C3		

Power Network Monitoring	Ye	es
Island Protection Monitoring	Yes	
Earth Fault Detection	Yes	
DC Input Switch	Ye	es
Overvoltage Load Drop Protection	Ye	es
Residual Current (RCD) Detection	Ye	es
Surge Protection Level	TYPE II(DC),	TYPE II(AC)
Interface		
LCD/LED display	LC	CD
Communication Interface	WIFI,RS4	85, CAN
General Data		
Operating Temperature Range	-40 to +60 °C , >	∙45℃ Derating
Permissible Ambient Humidity	0-100%	
Permissible Altitude	200	0m
Noise	≤ 55 dB	
Ingress Protection(IP) Rating	IP 65	
Inverter Topology	Non-Isolated	
Over Voltage Category	OVC II(DC),	OVC III(AC)
Cabinet size(W*H*D) [mm]	408W×638H×237D (Excluding connectors and brackets)	
Weight(kg)	30	0.5
Installation Style	Wall-mounted	
Warranty	5 Years/10 Years the Warranty Period Depends the Final Installation Site of Inverter, More Info Please Refer to Warranty Policy	
Type of Cooling	Natural Cooling	Intelligent Air Cooling
Grid Regulation	IEC 61727,IEC 62116,CEI 0-21,EN 50549,NRS 097,RD 140, UNE 217002,OVE-Richtlinie R25,G99,VDE-AR-N 4105	
Safety EMC/Standard	IEC/EN 61000-6-1/2/3/4, IEC/	/EN 62109-1, IEC/EN 62109-2


Model	SUN-12K-SG01HP3- EU-AM2	SUN-15K-SG01HP3- EU-AM2	SUN-20K-SG01HP3- EU-AM2	SUN-25K-SG01HP3- EU-AM2
Battery Input Data	<u> </u>			
Battery Type		Lithiu	ım-ion	
Battery Voltage Range(V)	160-700			
Max. Charging Current(A)		37		50
Max. Discharging Current(A)		37		50
Charging Strategy for Li-ion Battery		Self-adapt	ion to BMS	
Number of Battery Input			1	
PV String Input Data				
Max. PV Input Power(W)	15600	19500	26000	32500
Max. PV Input Voltage (V)		10	00	
Start-up Voltage(V)		18	30	
MPPT Voltage Range(V)		150	-850	
Full Load MPPT Voltage Range(V)	340-850	420-850	500-850	625-850
Rated PV Input Voltage (V)		600		700
Max. Operating PV Input Current(A)	26+20	26+20	26+26	26+26
Max. Input Short-Circuit Current(A)	39+30	39+30	39+39	39+39
No. of MPP Trackers/No. of Strings per MPP Tracker	2/2	2+1	2/2	2+2
Max. Inverter Backfeed Current To the Array		()	
AC Input/Output Data				
Rated AC Input/Output Active Power(W)	12000	15000	20000	25000
Max. AC Input/Output Apparent Power(VA)	13200	16500	22000	27500
Peak Power (off-grid)(W)		1.5 time of rat	ed power, 10 S	
Rated AC Input/Output Current(A)	18.2/17.4	22.8/21.8	30.4/29.0	37.9/36.3
Max. AC Input/Output Current(A)	20/19.2	25/24	33.4/31.9	41.7/39.9
Max. Three-phase Unbalanced Output Current(A)	25	30	35	41.7
Max. Continuous AC Passthrough (grid to load)(A)		8	0	
Rated Input/Output Voltage/Range(V)		220/380V, 230/40	00V 0.85Un-1.1U	n
Grid Connection Form		3L+N	N+PE	
Rated Input/Output Grid Frequency/Range	5	0Hz/45Hz-55Hz	60Hz/55Hz-65H	z
Power Factor Adjustment Range		0.8 leading t	o 0.8 lagging	
Total Current Harmonic Distortion THDi		<3% (of non	ninal power)	
DC Injection Current		<0.5	% In	
Efficiency				
Max. Efficiency		97.0	60%	
Euro Efficiency		97.0	00%	
MPPT Efficiency	>99%			
Equipment Protection				
DC Polarity Reverse Connection Protection	Yes			
AC Output Overcurrent Protection	Yes			
AC Output Overvoltage Protection		Ye	es	
AC Output Short Circuit Protection	Yes			
Thermal Protection	Yes			
DC Terminal Insulation Impedance Monitoring	Yes			
DC Component Monitoring		Ye	es	
Ground Fault Current Monitoring		Ye	es	

Power Network Monitoring	Yes
Island Protection Monitoring	Yes
Earth Fault Detection	Yes
DC Input Switch	Yes
Overvoltage Load Drop Protection	Yes
Residual Current (RCD) Detection	Yes
Surge Protection Level	TYPE II(DC), TYPE II(AC)
Interface	
LCD/LED display	LCD
Communication Interface	WIFI,RS485, CAN
General Data	
Operating Temperature Range	-40 to +60 °C , >45 °C Derating
Permissible Ambient Humidity	0-100%
Permissible Altitude	2000m
Noise	≤ 55 dB
Ingress Protection(IP) Rating	IP 65
Inverter Topology	Non-Isolated
Over Voltage Category	OVC II(DC), OVC III(AC)
Cabinet size(W*H*D) [mm]	408W×638H×237D (Excluding connectors and brackets)
Weight(kg)	30.5
Installation Style	Wall-mounted
Warranty	5 Years/10 Years the Warranty Period Depends the Final Installation Site of Inverter, More Info Please Refer to Warranty Policy
Type of Cooling	Intelligent Air Cooling
Grid Regulation	IEC 61727,IEC 62116,CEI 0-21,EN 50549,NRS 097,RD 140, UNE 217002,OVE-Richtlinie R25,G99,VDE-AR-N 4105
Safety EMC/Standard	IEC/EN 61000-6-1/2/3/4, IEC/EN 62109-1, IEC/EN 62109-2


9. Appendix I

Definition of RJ45 Port Pin for BMS1

No.	RS485 Pin
1	485_B
2	485_A
3	GND_485
4	CAN-H1
5	CAN-L1
6	GND_485
7	485_A
8	485_B




BMS1 Port



Definition of RJ45 Port Pin for BMS2


No.	RS485 Pin
1	485_B
2	485_A
3	GND_485
4	CAN-H2
5	CAN-L2
6	GND_485
7	485_A
8	485_B


BMS2 Port



Definition of RJ45 Port Pin for Meter


No.	Meter-485 Pin
1	METER-485_B
2	METER-485_A
3	GND_COM
4	METER-485_B
5	METER-485_A
6	GND_COM
7	
8	






Definition of RJ45 Port Pin for RS485

No.	RS485 Pin
1	Modbus-485_B
2	Modbus-485_A
3	GND_485
4	
5	
6	GND_485
7	Modbus-485_A
8	Modbus-485_B




RS485 Port



RS232

No.	WIFI/RS232
110.	VV 11 1/ 103232
1	
2	TX
3	RX
4	
5	D-GND
6	
7	
8	
9	12Vdc




WIFI/RS232

This RS232 port is used to connect the wifi datalogger

10. Appendix II

- 1. Split Core Current Transformer (CT) dimension: (mm)
- 2. Secondary output cable length is 4m.



11. EU Declaration of Conformity

within the scope of the EU directives

- Electromagnetic compatibility 2014/30/EU (EMC)
- Low Voltage Directive 2014/35/EU (LVD)
- Restriction of the use of certain hazardous substances 2011/65/EU (RoHS)

()

NINGBO DEYE INVERTER TECHNOLOGY CO., LTD. confirms herewith that the products described in this document are in compliance with the fundamental requirements and other relevant provisions of the above mentioned directives. The entire EU Declaration of Conformity and certificate can be found at https://www.deyeinverter.com/download/#hybrid-inverter-5.



231011005

www.deyeinverter.com

EU Declaration of Conformity

Product: Hybrid Inverter

Models: SUN-5K-SG01HP3-EU-AM2;SUN-6K-SG01HP3-EU-AM2;SUN-8K-SG01HP3-EU-AM2; SUN-10K-SG01HP3-EU-AM2;SUN-12K-SG01HP3-EU-AM2;SUN-15K-SG01HP3-EU-AM2; SUN-20K-SG01HP3-EU-AM2;SUN-25K-SG01HP3-EU-AM2;

Name and address of the manufacturer: Ningbo Deye Inverter Technology Co., Ltd. No. 26 South YongJiang Road, Daqi, Beilun, NingBo, China

This declaration of conformity is issued under the sole responsibility of the manufacturer. Also this product is under manufacturer's warranty.

This declaration of conformity is not valid any longer: if the product is modified, supplemented or changed in any other way, as well as in case the product is used or installed improperly.

The object of the declaration described above is in conformity with the relevant Union harmonization legislation: The Low Voltage Directive (LVD) 2014/35/EU;the Electromagnetic Compatibility (EMC) Directive 2014/30/EU;the restriction of the use of certain hazardous substances (RoHS) Directive 2011/65/EU.

References to the relevant harmonized standards used or references to the other technical specifications in relation to which conformity is declared:

LVD:	
EN 62109-1:2010	•
EN 62109-2:2011	•
EMC:	
EN IEC 61000-6-1:2019	•
EN IEC 61000-6-2:2019	•
EN IEC 61000-6-3:2019	•
EN IEC 61000-6-4:2019	•
EN IEC 61000-3-2:2019+A1:2021	•
EN 61000-3-3:2013/A2:2021/AC:2022-01	•
EN IEC 61000-3-11:2019	•
EN 61000-3-12:2011	•
EN 55011:2016/A2:2021	•

Nom et Titre / Name and Title:

Au nom de / On behalf of: Date / Date (yyyy-mm-dd): A / Place:

EU DoC - v1

Bard Dai Senior Standard and Sertification En

Ningbo Deye Inverter Technology Co., Ltd. 2023-10-11 Ningbo, China

Ningbo Deye Inverter Technology Co., Ltd. No. 26 South YongJiang Road, Daqi, Beilun, NingBo, China

Ver: 2.2, 2024-01-25

NINGBO DEYE INVERTER TECHNOLOGY CO., LTD.

Add.: No.26 South Yong Jiang Road, Dagi, Beilun, Ning Bo, China

Tel.: +86 (0) 574 8622 8957

Fax.: +86 (0) 574 8622 8852

E-mail: service@deye.com.cn

Web.: www.deyeinverter.com



30240301002153